

ASSEMBLY INSTRUCTIONS


ITEM NO: BO-2844FL-1

CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE.

1. SCREW POLE (2) TO BASE (1) CLOCKWISE TO TIGHTEN.
2. TURN KNOB (4) COUNTER-CLOCKWISE TO LOOSE, PULL POLE (3) UP OR DOWN TO DESIRED OVERALL HEIGHT, TURN KNOB (4) CLOCKWISE TO TIGHTEN.
3. INSTALL THE HANDLE (5).
4. JOIN THE ADAPTER (6).
5. INSERT THE POWER PLUG INTO AN OUTLET.
6. CLICK THE DIMMER SWITCH TO TURN ON OR OFF THE LIGHT, PUSH FOR MORE THAN 3 SECONDS TO DIMMER. AND ADJUST THE HANDLE AND SWING ARM TO DESIRED ANGLE.

YOUR LAMP IS NOW READY TO ENJOY!!!

Use 10 Wattage LED bulb (bulb included)



SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.